

Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.
1	18371-C	Electrical Assembly	1	14	18393-A	Blank Plate	1	27	18121-B	Motor Support Plate	1	40	18284-C	Table Assembly	1
2	182T	3hp 230/460v. Motor	1	15	18112-A	Speed Chart	1	28	18218-A	Motor Clamp Plate	2	41	18137-A	Rear Saw Band Guard	1
3	18246-A	Grob Vari-Drive Pulley	1	16	18128-A	Cover	1	29	18117-B	Motor Slide Channel	1	42	18190-C	Column Door	1
4	18122-A	Air Blower Support Plate	1	17	18390-A	Speed Adj. Handwheel	1	30	18105-B	Lower Saw Pulley	1	43	18130-C	Head Assembly	1
5	18127-A	Speed Indicator Pointer	1	18	18182-A	Speed Adjustment Screw	1	31	GS-2079-A	18" Pulley Tire	2	44	18175-D	Frame	1
6	18111-B	Sawing Chart	1	19		3/4-10 Jam Nut	2	32	18295-A	Table Support Pin	2	45	18180-C	Transmission Assembly	1
7	18321-A	Push Button Plate	1	20	HS-398-A	Spacer	1	33	18372-A	Door Latch Assembly	2	46	18055-C	Drive Pulley	1
8	18323-A	Gasket	1	21	18210-A	Speed Adjustment Nut	1	34	18104-B	Base Door	1	47	18156-D	Concrete Base	1
9	Start Button	CH 10250T30B	1	22	18183-A	Spacer	1	35	18292-A	Lower Stabilizer Channel	1	48	18135-B	Rear Lower Base Cover	1
10	Stop Button	CH 10250T30R	1	23	S-1167-A	Washer	1	36	18260-B	Lower Saw Band Guard	1	49	18118-B	Rear Base Support Channel	1
11		Push Button Box	1	24	FF-620-5	Oilite Bushing	1	37	18267-A	Lower Guard Extension	1	50	18174-B	Leg for Frame	4
12	GS-2286-B	Blank Plate	1	25		5/16 Flat Washer	1	38	18293-A	Upper Stabilizer Channel	1	51	18189-A	Leg Cover	4
13	18247-A	2322V601 Drive Belt	1	26		5/16-18 x 1/2 Hex Bolt	1	39	18291-A	Upper Table Support Brkt.	1	52	GS-2077-A	Lower Wheel Brush Ass'y.	1

